



DOC002



01245 222774/ TEAM@KI-SL.CO.UK

EQUINOX VAPOUR 1000 HAZE MACHINE USER GUIDE

1. Install the unit on a level surface. Ensure the machine has the required liquid (provided by KI Sound & Light) before plugging in any cables. **Do not put liquid into the machine while it is connected to any power.**
2. Plug the vapour 1000 into the mains using an IEC power cable.
3. Turn the power switch to on and allow two minutes for the machine to heat up. The LED screen will display “up” while the machine is heating up.
4. Once the machine has heated up the LED screen will display ‘read’ indicating that it is ready to use.
5. On the LED screen you can adjust the ‘F’ on the menu, selecting up and down to adjust the amount of haze produced from 0-100%. You can simply leave the haze machine during your event or adjust it as needed.
6. Once you have finished using the hazer simply use the off button to turn it off. Please allow the hazer to sit for a minimum of 10 minutes before putting it back into the bag to allow for cool down and the machine to finish letting out leftover haze.

NOTES:

The equinox vapour 1000 hazer can be controlled manually or via DMX.

WARNING

The fluid tank of the unit needs to be filled with haze fluid before switching on. Only use quality haze fluids provided by KI Sound & Light. You must not use any other substances inside the machine. If fluid should get inside the main housing, disconnect the unit from the mains immediately. Install the unit in a well-ventilated area. Use in an insufficiently ventilated room can lead to the condensation of the haze fluid. The resulting slippery surface can cause accidents. Keep a minimum distance of 1m around the unit. Furthermore do not orientate the output nozzle directly in the direction of the audience’s eyes. Only install the haze machine on fire resistant, scratch resistant and water resistant surfaces. This product may set off fire and smoke alarms so please check these before use.